


## V55 Pro | Quick Start Guide




### ILIFE Customer Service

Toll-Free Number:  
 1-800-631-9676 (USA and Canada)  
 +86-75521005927 (Outside USA and Canada)

Before You Get Started | See How V55 Pro Works


### 1. Positioning the charging dock

- Please the charging dock against a wall and connect the adapter to an outlet. It is suggested to leave an area with at least 4 feet (1 meter) on each side of the charging dock, and at least 8 feet (2 meters) in front of the charging dock. Do not place the charging dock around doors and stairs.



### 2. Wake up and charge your robot

- Turn on the power switch at the side of body, then place your robot on the charging dock for a full charge.



- Always keep the power switch turned on during your daily use. Turn off the power switch only when you don't use your robot for more than one week.

### • V55 Pro is ready to clean

#### 1 Switch on the robot

- Make sure the power switch at the bottom of the robot is turned on.
  - Press on the robot or on the remote control to start cleaning.
- \* To switch from sleep mode to select mode, press . Press again to start cleaning.

#### 2 Pause

- Pause the robot to switch from cleaning mode to select mode.
- Press button on the robot.
  - Press button on the remote control.

#### 3 Sleep

- Robot enters sleep mode when it is not working with signal light off.
- Robot enters sleep mode if it does not receive any commands in 20 seconds.
  - Press and hold on the display for 3 seconds to enter sleep mode.

### • Scheduling

#### • How to schedule


The robot can be scheduled to clean at a specific time in the next 24 hours. (E.g. If you schedule a cleaning time of 06:30 at 10:00 am, then the robot will start cleaning at 16:30 everyday till the schedule is cancelled.)

### • Setting a schedule

- Press 'CLEAN'. (If there is no notifications showing on the display.)
- Press 'PLAN'. The first 2 digits showing the hours are flashing.
- Use 'HOME' or 'SPOTS' key to set the hours (01 - 23).
- Press 'PLAN' again. The last 2 digits showing the minutes are flashing.
- Use 'HOME' or 'SPOT' key to set the minutes (00,15,30,45).
- Press 'CLEAN' to confirm the settings.
- If the power switch on the side of the robot is turned off, all the previous schedules will be canceled.

### • Install water tank and mop cloth

- Open the water tank cap and slowly fill in water.
- Close the cap. Install the mop cloth and its holder. Make sure it is securely attached to the base of the robot.




Note:

- Remove water tank and mop cloth before cleaning carpeted floors.
  - Make sure the mop cloth is not in contact with or does not cover the wheels.
- Warning: Always avoid water on external sensors and in the internal of the robot.

### • Robot maintenance

- For better cleaning performance, empty dustbin and clean high performance filter after each use (High Performance Filter can't be washed with water). Replace with a new when it is needed.
- In homes with heavily shedding pets, dustbin may fill quickly with fur or hair. In these cases, you may need to empty dustbin and clean filters more frequently.



### • Troubleshooting

When the robot meets with some common alerts shown on the display.

Alert code	Possible cause	Solutions
E01	Left side wheel isn't rotating	Check the condition of left side wheel
E02	Right side wheel isn't rotating	Check the condition of the right side wheel
E04	Robot isn't on a flat surface	Move the robot to a flat surface
E05	Cliff sensor error	Clean the cliff sensor. Contact our repair service if problem persists.
E06	Bumper sensor error	Check the flexibility of the bumper and if there's anything stuck in it.
E07	Left side brush isn't working	Check the condition of the left side brush
E08	Right side brush isn't working	Check the condition of the right side brush
E09	Robot gets stuck	Move the robot and restart
E10	The power switch at the bottom is off when charging.	Switch on the power at the bottom when charging the robot.
LO	Battery voltage is low	Turn on the power switch at the bottom of the charging dock
<b>The indicator  and  keep on</b>	Dustbin is full or vent is stuck	- Empty the dustin - Clean the vent

Note: If all above solutions don't work, please take below actions.

- Re-set the robot by re-turning on the power switch.
- If re-set action doesn't work, please contact [support@iliferobot.com](mailto:support@iliferobot.com)